


## DREHTELLERMODUL

### FUNKTION

Mit dem Drehtellermodul können die Werkstückträger von einem Umlauf zum anderen geleitet werden. Die Ketten müssen in entgegengesetzter Richtung laufen.

### ZEICHNUNG



## TECHNISCHE DATEN

Siehe Dokumentation von der Firma Lenze.

Störung	Massnahmen
- Flipper dreht nicht	- Pneumatische Zuleitungen kontrollieren - Auf mechanisches Blockieren untersuchen
- Motor dreht nicht	- Elektrische Zuleitungen überprüfen.

## WARTUNG

Nr.	Beschreibung	Intervall <sup>1</sup>	Wartung
1	Drehtellermodul	M	Reinigen
2	Drehtellermodul	M	Kontrolle Funktionen, Beschädigungen




H: Stunde S: Schicht W: Woche M: Monat J: Jahr

## VERSCHLEISSTEILE / ERSATZTEILE

Nr.	Bezeichnung
1	Grundplatte
2	Drehteller

<sup>1</sup> Je nach Verschmutzungsgrad und Auslastung

ELEKTRISCHER ANSCHLUSS UND PNEUMATISCHE STEUERUNG




## TURNTABLE MODULE

### FUNCTION

The turntable module is used to redirect pallets from one chain to another. The chains must be running in opposite directions.

### DRAWING



---

## TECHNICAL DATA

Siehe Dokumentation von der Firma Lenze.

---

Malfunction	Trouble shooting
- Flipper doesn't swivel	- check pneumatic hoses - check for mechanical blockage
- Motor doesn't turn	- check cables

---

## MAINTENANCE

No.	Description	Interval <sup>2</sup>	Maintenance
1	Turntable Module	M	Cleaning
2	Turntable module	M	Inspection of all functions and for damages

H: Hour S: Shift W: Week M: Month J: Year

---

## WEAR PARTS / REPLACEMENT PARTS

No.	Description
1	Base Plate
2	Turntable

---

<sup>2</sup> Depending on cleanliness and usage

ELECTRIC AND PNEUMATIC CONTROL

